

Mi-Witness HD Camera Vision Plus System and External Cameras.

The Mi-Witness Vision plus allows you to connect almost any external camera to the Mi-Witness and add a monitor to view the rear camera allowing the Mi-Witness to be used as a reversing camera.

The Vision Plus cable is plug and play and can take any optional camera with a standard RCA video feed or you can utilise our standard Mi-Witness rear camera. Again almost any monitor can be used to view the video feed off the rear camera. The video feed can not be viewed from the main camera this way.

External Cameras

There are two types of external cameras available from TTW, however we can supply other types of camera if needed.

- Type 1 is a bracket mounted or hole mounted 12 volt camera
- Type 2 is a bracket mounted Infrared camera for daylight and low light applications. (Shown in image below)

Wiring for the cameras is simple, the optional camera needs its own 12 volt power supply and the video feed is sent directly to Mi-Witness via the vision plus cable. There is a Mirror/No Mirror view option on some cameras controlled by either a switch or by cutting/connecting a wire. You need to check on the cameras own manual to see if this feature is available.

It is important to remember that the it may be illegal in your country to have the monitor switched on while your driving and should only be used during reversing. We also suggest that the rear camera is ignition fed or connected to the Smart Power system should you be using the Smart Power to protect your battery

Typical wiring example.

